

# Oven, Hob & Grill

Rangemaster Toledo 90 Dual Fuel

01

A five-burner gas hob with a separate ignition button, a main fan oven, a second side oven and a grill.

## BEFORE YOU START — SET THE CLOCK

If the cooker has been switched off at the wall, the clock must be reset before the ovens will work.

## SETTING THE CLOCK

- 1 Press the + and – buttons together.
- 2 The centre dot between the hours and minutes will flash.
- 3 While it is flashing, press + or – to set the correct time.
- 4 The cooker uses a 24-hour clock.
- 5 Once set, the cook symbol appears and the ovens can be used.

## LIGHTING THE GAS BURNERS

- 1 Press the igniter button — the burners will spark.
- 2 While it sparks, push in and turn the burner control to the large flame symbol.
- 3 Keep the control pressed in for about ten seconds once it lights, then release.
- 4 Turn towards the small flame symbol to lower the heat.
- 5 If a burner goes out, turn it off, wait one minute, then try again.

## OVENS AND GRILL

- **Main oven** — for main dishes. Turn its control to the temperature and let it preheat.
- **Side oven** — for smaller dishes, or two dishes at different temperatures.
- **Grill** — open the door and pull the grill pan carriage forward by its handle. Turn the control clockwise for the full grill, anticlockwise for the right-hand half only.

## GOOD TO KNOW

Please use the extractor fan whenever you are frying.

## SAFETY

- Never close the grill door while the grill is on.
- Never leave frying unattended — hot fat or oil can catch fire.
- The appliance and its accessible parts get very hot and stay hot after use.



## FULL MANUFACTURER MANUAL

### Rangemaster Toledo 90 Dual Fuel — full user guide

[https://www.rangemaster.co.uk/sites/default/files/user\\_guides\\_uploaded/U111243-02a%20TOLEDO%2090%20DUAL%20FUEL%20\[GB\].pdf](https://www.rangemaster.co.uk/sites/default/files/user_guides_uploaded/U111243-02a%20TOLEDO%2090%20DUAL%20FUEL%20[GB].pdf)