

Microwave

Kenwood K30GMS21 — 30 litre, 900 W with grill

04

For reheating, simple cooking and grilling. Use microwave-safe dishes only.

HEATING SOMETHING

- 1 Put the food in a microwave-safe dish.
- 2 Press **Power Level** to choose the power: P-HI (full), P-80, P-60, P-40 or P-20.
- 3 Turn the **Menu/Time** dial to set the time.
- 4 Press **Start/+30Sec.**
- 5 Press **Stop/Cancel** once to pause, twice to stop.

DEFROSTING

- 1 Press **Weight Defrost**.
- 2 Press **Clock/Weight** to set the weight, between 100 g and 1800 g.
- 3 Press **Start/+30Sec.** It pauses and beeps partway through to tell you to turn the food.

GRILLING

- 1 Press **Grill/Combo**, set the time with the dial, then press Start.
- 2 Use the grill rack provided and turn the food halfway through.

GOOD TO KNOW

The child lock switches itself on after about a minute in standby. Opening and closing the door releases it — the microwave is not broken.

SAFETY

- Never run the microwave empty — it damages the machine.
- No foil and no metal containers.
- Check food is piping hot all the way through before serving, and take care with hot liquids.



FULL MANUFACTURER MANUAL

Kenwood K30GMS21 — user manual

<https://manuals.co.uk/kenwood-k30gms21-microwave/>